## Stage 0 - Instructions

This lab should be done by a groups of 2 students. Students shall produce various documents:

- An export of a portable gns3 project called lab1.GROUP\_NB.gns3project
- A Markdown document called lab1.GROUP\_NB.md (french or english accepted not a mix of both)
- This document should be readable as a tutorial containing the answers to this lab.
- the following lines should be present at the top of this document (this is used by pandoc to generate a beautifull pdf):

```
title: "B2 - Lab 1"
author:
- GROUP MEMBER 1
- GROUP MEMBER 2
output:
 pdf_document: default
```

- images should be included in an images/ folder (only png and jpeg/jpg allowed)
- Included images should be included like so: ![NOM DE LA FIGURE](images/FILENAME.EXT) in the document.

Thoses various documents should be compressed in an archive called lab1.GROUP\_NB.zip.

Once unarchived we should have the following structure:

```
lab1.GROUP_NB.zip
lab1.GROUP_NB
    images
    bar.jpeg
    foo.png
    lab1.GROUP_NB.gns3project
    lab1.GROUP_NB.md
```

This final zip should be send via email your teacher.

Be sure you read all of this document before starting the exercise.

If you have any doubt you mays express them.

Of course internet is allowed.

# Stage 1 - Initialization

Create a new blank gns3 project called Lab1.

Spawn a NAT appliance and call it LeNatXX where XX is your group number.

Spawn an OpenWrt 19.07.4 appliance and call it Le\*Router

Connect LeNatXX to the wan port of Le\*Router

### Stage 2 - OpenSSH access

Install & config openssh on port XX22 Install openssh-server and start it on Le\*Router.

Create a firewall rule named Allow SSH that allows connections from wan on port XX22 where XX is your group number.

On your host generate a key with ED25519 format and explain briefly the current advantages (as of 2020) of this format.

With your configuration, you should be be able to login with root from your host.

```
Hint (Unix): ssk-keygen
Hint (windows): use pyttygen
```

## Stage 3 - LuCi

Configure luci do listen on localhost:80 ipv4 only and list 2 ways to listen to localhost only (in this context).

Configure your ssh server to enable port forwarding and explain what it is.

Hint: click here

Use luci only like in the hint from before.

# Stage 4 - Lan

Configure Le\*Router to use a class A, with a mask of 16 bits the second byte of the lan network should be your group number.

Find which RFC defines what are the reserved ips for our use case. List and explain all of the available ip prefixes.

Add an Alpine linux appliance called LeWebServer and connect it to the lan.

# Stage 5 - HTTP

Configure nginx to serve basic files from port XX80 on LeWebServer where XX is your group number.

Serve static files with nginx the following file should be served as index:

# </body>

hint: click me!

Using a tool to download the missing pdf from into the files served so that the pdf is downloadable from that page.

Use and Show 2 different commands to download the file in the served nginx folder.

hint: you are encouraged to bookmark me and read me later

Verify that the setup is working by downloading the pdf from your host.

### Stage 6 - Make it generic

Add a an ethernet switch between LeWebServer and Le\*Router.

Add a static ip (10.XX.2.1) for LeWebServer.

# Stage 7 - Make your own

Create 2 separates subnets and put LeWebServer in one of them. Add another alpine linux and make it get the file without adding a route to the other network.

## Stage 8 - Wrap up

Choose at least 4 protocols that you used during this Lab, name them and describe them and give a link to their(s) respectives RFCs or spec.

# Stage 9 - I have finished the Lab

If you vahe finished this lab, ask the teacher, additional instructions will be delivered to you.